



- Remove Hinge
- cutout Template and use to mark hinge for cutting & Drilling
- Notch marked section of hinge (I used Dremel Tool)
- File rough edges smooth
- Drill (3) holes 3/16" and counter sink
- Check hinge fit on panel and file hinge as needed.
- Hinge should fold flat against back side of panel
- When panel is mounted in boat, you may need to drill wood holes behind hex nuts that attach hinge to panel
- Use the guide above to drill pilot holes in wood to mount hinge.